Table Of Contents

SECTION 1: OVERVIEW 1-1

SECTION 2: SPECIFICATIONS 2-1

SECTION 3: PREVENTATIVE MAINTENANCE 3-1

SECTION 4: COMPONENT LOCATION 4-1

SECTION 5: INSTALLATION & ADJUSTMENT PROCEDURES

Installation Procedures

1. Envelope Feeder 5-1
2. Mounting Bracket 5-1
3. Equipment Quality Report 5-3

Adjustment Procedures

1. Stripper Height 5-4
2. Envelope Side Guides 5-5
3. Transport Rollers 5-6
4. Side to Side Registration 5-8
5. Back Support Guide 5-8
6. Testing AR8100 Feed Properties 5-9

SECTION 6: WIRING DIAGRAMS

1. Point to Point 6-1
2. Interface Cable Connection 6-2
3. Interface Cable 6-3

SECTION 7: TROUBLESHOOTING 7-1

SECTION 8: PARTS LAYOUT

1. Group 1 8-1
2. Group 2 8-6
3. Group 3 8-8
4. Group 4 8-10
5. Group 5 8-12
6. Metering Plate Assembly 8-14
7. Transport Assembly 8-15
8. Console 8-16